



V1.0.0

# Conventional Fire Alarm Control Panel

DHI-HY-C102-4

*Conventional Fire Alarm Control Panel*

*User's Manual*



TZ00384193

**ZHEJIANG HUAXIAO TECHNOLOGY CO.,LTD.**

Address: Area A, Floor 3, Building C, No.28 Dongqiao Road, Dongzhou Sub-district,  
Fuyang District, Hangzhou City, Zhejiang Province, China  
Website: [www.wisualarm.com/en/home](http://www.wisualarm.com/en/home)

【 User's Manual 】






## Foreword

### General

This manual introduces the functions and operations of the Conventional Fire Alarm Control Panel (hereinafter referred to as "the Device").

### Safety Instructions

The following categorized signal words with defined meaning might appear in the manual.

Signal Words	Meaning
 <b>DANGER</b>	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
 <b>WARNING</b>	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
 <b>CAUTION</b>	Indicates a potential risk which, if not avoided, could result in property damage, data loss, lower performance, or unpredictable result.
 <b>TIPS</b>	Provides methods to help you solve a problem or save you time.
 <b>NOTE</b>	Provides additional information as the emphasis and supplement to the text.

### About the Manual

- The manual is for reference only. If there is inconsistency between the manual and the actual product, the actual product shall prevail.
- We are not liable for any loss caused by the operations that do not comply with the manual.
- The manual would be updated according to the latest laws and regulations of related jurisdictions. For detailed information, refer to the paper manual, CD-ROM, QR code or our official website. If there is inconsistency between paper manual and the electronic version, the electronic version shall prevail.
- All the designs and software are subject to change without prior written notice. The product updates might cause some differences between the actual product and the manual. Please contact the customer service for the latest program and supplementary documentation.
- There still might be deviation in technical data, functions and operations description, or errors in print. If there is any doubt or dispute, we reserve the right of final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and the company names in the manual are the properties of their respective owners.
- Please visit our website, contact the supplier or customer service if there is any problem occurring when using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

## Important Safeguards and Warnings

This section introduces content covering the proper handling of the device, hazard prevention, and prevention of property damage. Read carefully before using the device, comply with the guidelines when using it, and keep the manual safe for future reference.

### Operation Requirements



- Make sure that the power supply of the device works properly before use.
- Transport, use and store the device under allowed humidity and temperature conditions.
- Prevent liquids from splashing or dripping on the device. Make sure that there are no objects filled with liquid on top of the device to avoid liquids flowing into it.
- Do not disassemble the device.

### Installation Requirements



#### WARNING

- Strictly abide by local electrical safety standards, and make sure that the voltage in the area is steady and conforms to the power requirements of the device.
- Do not connect the device to more than one power supply. Otherwise, the device might become damaged.



- Observe all safety procedures and wear required protective equipment provided for your use while working at heights.
- Do not expose the device to direct sunlight or heat sources.
- Do not install the device in humid, dusty or smoky places.
- Install the device in a well-ventilated place, and do not block the ventilator of the device.

### Maintenance Requirements



- Use the accessories suggested by the manufacturer. Installation and maintenance must be performed by qualified professionals.
- Clean the device with a soft dry cloth or a clean soft cloth dipped in neutral detergent.
- Contact your local dealer or the service center nearest to you if the device needs internal configuration or maintenance. Do not dismantle or modify the device without a qualified professional present to avoid the risk of danger or damage to the device. We will assume no responsibility for any problems caused by unauthorized modifications or maintenance.

## Table of Contents

<b>Foreword</b> .....	<b>01</b>
<b>Important Safeguards and Warnings</b> .....	<b>02</b>
<b>1 Product Information</b> .....	<b>04</b>
<b>2 Technical Information</b> .....	<b>05</b>
<b>3 Structure</b> .....	<b>06</b>
3.1 Dimensions.....	06
3.2 Composition .....	06
3.3 Front Panel.....	07
<b>4 Device Installation and Debug</b> .....	<b>10</b>
4.1 Packing List.....	10
4.2 Inspection .....	10
4.3 Installation .....	10
4.3.1 Principle .....	10
4.3.2 Wiring .....	12
4.3.3 Battery .....	13
4.4 System Debugging.....	14
4.4.1 Preparation .....	14
4.4.2 Alarm Test .....	14
4.4.3 Disconnection Test .....	14
4.4.4 Update Firmware By U Disk .....	14
4.4.5 Import Configurations By U Disk .....	15
4.4.6 RS485 Networking.....	15
<b>5 FAQ</b> .....	<b>16</b>
<b>6 Maintenance</b> .....	<b>17</b>

# 1

## Product Information

DHI-HY-C102-4 Conventional Fire Alarm Control Panel is designed and manufactured in compliance with EN54 Parts 2 & 4 requirements. It provides the advanced capabilities of a cutting-edge conventional fire alarm system, combined with the ease of use and effective installation that building users and installers require. As the core of a conventional fire alarm system, it cooperates with a comprehensive range of auxiliary devices, including smoke detectors, heat detectors, sounder strobes, and manual call points, to construct a fire alarm control system. With Ethernet, RS-485, and other IoT ports, it can integrate with other panels and connect to platforms.

# 2


## Technical Information

Parameter	Introduction
Main Power Supply	AC 110-220V/50Hz, 60Hz
Rated Power	50W
Working Voltage	DC24V
Backup Power Supply	2 lead-acid batteries (12V/2.5Ah each)
Dimensions	310.0 mm×73.0 mm×227.0 mm (12.20" × 2.87" × 8.94")
Weight	4.5 kg (with 2 batteries)
Operating Temperature	-10°C to +50°C (+14°F to +122°F)
Operating Humidity	≤ 95% RH (no condensation)
Protection	IP30

# 3 Structure

## 3.1 Dimensions

Figure 3-1 Dimensions (mm[inch])



## 3.2 Composition

- 4 zones: Max. 32 conventional devices in one zone
- 2 alarm bell outputs: Output DC 28V/500mA
- 1 fire alarm output: Output closing switch during a fire alarm
- 1 fault output: Output closing switch during a fault alarm
- 4 input detection lines: Detect external input switch
- 1 RS-485: Enable networking with control panels
- 1 RS-232: Reserved port
- 1 USB: Configure and upgrade the panel with USB
- 1 RJ45: Communicate with platform

## 3.3 Front Panel

Figure 3-2 Front panel





Table 3-1 Front panel introduction

Name	Introduction
Indicator	<ul style="list-style-type: none"> <li>● Fire: Remain lit after this zone receiving fire information. The LED turns off when the panel is reset.</li> <li>● Fault: Remain lit after this zone detecting fault. The LED turns off when the panel is reset or the fault is addressed.</li> <li>● Disable: Remain lit when this zone is disabled.</li> <li>● FIRE: Remain lit after receiving fire information.</li> <li>● Mains Supply: Remain lit when FACP is powered by main power.</li> <li>● Aux.-n (n=1~4): Remain lit when switch is closed.</li> <li>● Mains Fault: Remain lit when the main voltage is low.</li> <li>● Low Battery: Remain lit when the battery voltage is under 24V.</li> <li>● Communication: Remain lit when control panel connects to network, and flash when a fire occurs</li> <li>● Battery: Remain lit when FACP working voltage is supplied by battery only.</li> <li>● Battery Fault: Remain lit when backup voltage is under 22V.</li> <li>● Sounder Active: Remain lit when light and audible alarm is triggered.</li> <li>● General Fault: Remain lit when FACP receives fault information. (Press <b>Reset</b> button to turn off General Fault indicator)</li> <li>● Manual Call Point: Remain lit after receiving fire information from manual call point.</li> <li>● System Fault: Remain lit when the system is not functioning properly.</li> <li>● Sounder Fault: Remain lit when sounder strobe fails to start.</li> <li>● General Disable: Remain lit when any zone is disabled.</li> <li>● Debug: Remain lit when the panel is in debug mode.</li> <li>● Accumulate: Press <b>Accumulate</b> and <b>Panel Buzzer Silence</b> button to enter level-2, Accumulate indicator remains lit. If permission is insufficient, the light flashes.</li> <li>● Admin Control: Press <b>Admin Control</b> and <b>Panel Buzzer Silence</b> button to enter level-3, Admin Control indicator remains lit. When both level-2 and level-3 lights are off, it enters level-1. Press and hold <b>Admin Control</b> button under level-3 permission to debug the device.</li> <li>● Reset: Remain lit when the panel is in reset mode.</li> <li>● Disconnection Test: Remain lit when the panel is in disconnection test mode.</li> <li>● Alarm Test: Remain lit when the panel is in alarm test mode.</li> <li>● Panel Buzzer Silence: Remain lit when the buzzer is silenced.</li> <li>● Remote Sounder Silence: Remain lit when remote sounder silence is enabled.</li> </ul>

Name	Introduction
Functionality Button	<ul style="list-style-type: none"> <li>● Accumulate: Press <b>Accumulate</b> and <b>Panel Buzzer Silence</b> button to enter level-2, Accumulate indicator remains lit. If permission is insufficient, the light flashes. Press and hold <b>Accumulate</b> button to enter the main-sub registration. Functions that can be used in level-2 include Reset, Remote Sounder Silence, Disable/Disable cancelled, Disconnection Test, Alarm Test, main-sub registration.</li> <li>● Admin Control: Press <b>Admin Control</b> and <b>Panel Buzzer Silence</b> button to enter level-3, Admin Control indicator remains lit. When both level-2 and level-3 lights are off, it enters level-1. Press and hold <b>Admin Control</b> button under level-3 permission to debug the device. Functions that can be used in level-3 include Device debug, Update Firmware By U Disk, Import Configurations by U Disk.</li> <li>● Reset: During reset, Reset indicator remains lit, and is off after the reset is completed. Press the <b>Reset</b> button, FACP will reset within 20 seconds, the existing status and related information will be re-established within 20 seconds, and the fault information will be re-established within 100 seconds. Press and hold Reset button at level 2, the system will enter the self-test state.</li> <li>● Disconnection Test: Press <b>Disconnection Test</b> and <b>Zone Disable</b>, the system enters disconnection test, the Disconnection Test indicator remains lit. After completing disconnection test, press <b>Reset</b> to stop test.</li> </ul> <p> Disconnection test does not affect FACP's normal operation.</p> <ul style="list-style-type: none"> <li>● Alarm Test: Press <b>Alarm Test</b> and <b>Zone Disable</b>, the system enters alarm test, the Alarm Test indicator remains lit. Press <b>Zone Disable</b> button in different zones, its Fire indicator is on, FIRE indicator lights up, buzzer beeps, alarm signal and bell outputs. You can reset to clear alarm information. During the test, if a real fire occurs, FACP stops test automatically and addresses alarm.</li> <li>● Panel Buzzer Silence: When FACP sends out alarm signal, buzzer beeps. Press <b>Panel Buzzer Silence</b> to temporarily mute alarm. When a new alarm occurs, the buzzer activates again.</li> <li>● Remote Sounder Silence: Press <b>Remote Sounder Silence</b> to stop audible and light alarm.</li> </ul>
Buzzer	Alarm sound outlet.

# 4 Device Installation and Debug

## 4.1 Packing List

Check the package according to the following checklist. If you find anything damaged or lost, contact customer service.



Keep accessories properly for future use.

Table 4-1 Checklist

Item	Quantity
Conventional fire alarm control panel	1
User's manual	1
Key	2
Backup battery fuse	2

## 4.2 Inspection

- Disconnect all sources of power prior to installing or removing devices, connecting or disconnecting wiring.
- The Conventional Fire Alarm Control Panel receives main power from AC110V-220V supply. The positive and negative poles of the backup battery are correctly connected.
- Carry out self-test to check whether all parts are successfully inspected.
- The defective detectors should be dealt with according to "FAQ" and "Maintenance", and then test again. If it still fails to pass the test, it should be returned to the factory for repair.

## 4.3 Installation


### 4.3.1 Principle

- The FACP supports wall-mounted installation. It should be installed in the fire control room or the place where people are on duty. Keep away from the environment with electromagnetic interference.
- The design should be strictly implemented in accordance with relevant provisions and regulations, and connect the device correctly according to the construction drawing.
- During the system debugging process, please do not remove the dust cover of the device in advance to avoid false alarms during the decoration process.

**Step 1** Choose suitable place with convenient height for visual and manual access to FACP.

**Step 2** Drill four holes (Φ10 mm) on the wall and screw bolts.

Figure 4-1 Installation (1)



**Step 3** Place the cabinet over the four bolts.


**Step 4** Open the cabinet, tighten all four bolts securely against the back wall of the cabinet.



NOTE

Please ensure it is firm.

Figure 4-2 Installation (2)



4.3.2 Wiring

Before connecting the signal line and direct control line to the FACP, the insulation test should be carried out.  
The insulation resistance between loops is more than 10 KΩ, and insulation resistance between loops and ground is more than 10 MΩ.




This system does not require external end line resistors.

- Wiring should comply with the construction drawing and relevant regulations.
- Wires with different voltages and types should not be co-managed.
- Use RVS twisted pairs with a section area of 1.5 mm<sup>2</sup> or 1.0 mm<sup>2</sup> for the polarity-free signal buses with a communication distance of less than 1500 m.
- RS-485 BUS: Use RVS twisted pairs with a section area of 1.5 mm<sup>2</sup> with a communication distance of less than 1200 m.
- AC power cord (L, N,  $\perp$ ): Use a flame-retardant 3-core insulated wire with a withstand voltage of more than 750V.
- Grounding wire: Use a 4 mm<sup>2</sup> copper wire with a grounding resistance of less than 4Ω.

Figure 4-3 Wiring terminal

ZONE1	ZONE2	ZONE3	ZONE4	BELL1	BELL2	ALARM	FAULT	AUX1	AUX2	AUX3	AUX4
+ -	+ -	+ -	+ -	+ -	+ -	NO COM NC	NO COM NC	1 2	1 2	1 2	1 2

A	B	RS485
TX	TX	RS485
COM	COM	



ZONE terminal

ZONE<sub>n</sub> (n=1-4): Connect smoke detector, heat detector, manual call point, etc.

Alarm bell terminal

Bell1, Bell2: Power output terminal of alarm bell, output DC28V during fire alarm.

Other terminal

- FAULT: Fault output. When the FACP receives fault information, the normally open switch of the terminal becomes the normally closed switch.
- ALARM: Alarm output. When the FACP receives alarm information, the normally open switch of the terminal becomes the normally closed switch.
- AUX<sub>n</sub> (n=1-4): Receive input passive switching from other devices in the system.
- 232TX, 232RX, GND: Reserved port.
- 485A1, 485B1, 485A2, 485B2: RS-485 networking port for communication among control panels.

Main electrical terminal

L、N、 $\perp$  : AC 90V~240V power supply.

4.3.3 Battery




Connect the final battery after completing installation.

Step 1 Connect fuse.

Step 2 Connect the red and black power wires reserved in the wire slot to the positive and negative terminals of the battery respectively.

Figure 4-4 Battery





## 4.4 System Debugging

### 4.4.1 Preparation

After connection and verification, if all tests meet the requirements, then connect the loop line of the field equipment to the FACP correctly and carry out the test. The results should be filled in the debugging form for further reference. After the wiring is completed and checked correctly, start the debugging.



There is no need to access resistor in the end of line in the zone.

After connecting all detectors in every zone are connected, please debug for subsequent use.



Press **Admin Control** and **Panel Buzzer Silence** to enter level-3. Press and hold **Admin Control** to debug field device automatically.

During the debug mode, Debug indicator lights up. After debugging, Debug indicator turns off and FACP enters standby mode.

### 4.4.2 Alarm Test

- Press **Alarm Test** and **Zone Disable** to simulate alarm.

During the test, Alarm Test indicator lights up.

Press **Zone Disable** button in different zone, its Fire indicator is on, FIRE indicator lights up, buzzer beeps, alarm signal and bell outputs. You can reset to clear alarm information. During the test, if a real fire occurs, FACP stops test automatically and addresses alarm.

- Manual call point test

Press the manual call point to activate the alarm. After the test is completed, reset the manual call point, and then press the **Reset** button in the FACP to reset to stop the fire alarm test.

### 4.4.3 Disconnection Test

Press **Disconnection Test** and **Zone Disable** to simulate disconnection fault.

During the test, the Disconnection Test indicator lights up.

Press **Zone Disable** button in different zone, its Zone Fault indicator is on, General Fault indicator lights up, buzzer beeps, and fault signal outputs. Press **Reset** to stop the disconnection test.

### 4.4.4 Update Firmware By U Disk

**Step 1** Place the upgraded BIN file named "DHIC102" in the root directory of the U Disk.

**Step 2** Use the key to open the chassis and insert the U Disk into the U Disk port.

**Step 3** Press **Admin Control** and **Panel Buzzer Silence** button to enter level-3.

**Step 4** Press **Accumulate** and **Admin Control** button at level-3 to perform a U Disk upgrade.

**Step 5** After 3 seconds, the Debug indicator is always on, indicating that the upgrade process has begun.

During the upgrade, the System Fault indicator will be on, it is normal.

**Step 6** After the upgrade is complete, the Debug and System Fault indicators are off, and the control panel returns to the standby state



If the U Disk is not recognized, the Debug indicator will always be on. If the file is incorrect or the import fails, the Debug indicator will turn off until the **Manual Reset** is released.

### 4.4.5 Import Configurations By U Disk

Configure the RS485 networking between the host and the networking function between the host and the platform by the computer software named "ControlConfig".

**Step 1** Configure the settings on the ControlConfig and export the file renamed to "DHIC102.cfg" to the root directory of the U Disk.

**Step 2** Use the key to open the chassis and insert the U Disk into the U Disk port.

**Step 3** Press **Admin Control** and **Panel Buzzer Silence** button to enter level-3.

**Step 4** Press **Admin Control** and **Remote Sounder Silence** button at level-3 to perform a U Disk import.

**Step 5** After 3 seconds, the Debug indicator is always on, indicating that the import process has begun.

**Step 6** After the import is complete, the Debug indicator is off, and the control panel returns to the standby state.



If the U Disk is not recognized, the Debug indicator will always be on. If the file is incorrect or the import fails, the Debug indicator will turn off until the **Manual Reset** is released.

### 4.4.6 RS485 Networking

Realize the networking of RS485 main and sub devices.

**Step 1** Complete the configuration of main-sub mode on the ControlConfig.

**Step 2** Connect the main and sub devices through RS485A and RS485B terminals.

**Step 3** Press **Accumulate** and **Panel Buzzer Silence** button to enter level-2.

**Step 4** Press and hold **Accumulate** button at level-2 to enter the main-sub registration.

**Step 5** After 3 seconds, the Debug indicator is always on, indicating that the registration process has begun.

**Step 6** After the registration is complete, the Debug indicator is off, and the control panel returns to the standby state.



Only one main and a maximum of 128 sub devices can exist on a same RS485 circuit, and the addresses of the sub devices must be different.

# 5 FAQ

Problem	Analysis	Solutions
Fails to work normally after starting up	Abnormal power supply	<ul style="list-style-type: none"> <li>• Check mains power supply</li> <li>• Check the connection cable</li> </ul>
Mains Fault indicator is constantly on after starting up	<ul style="list-style-type: none"> <li>• No mains power supply</li> <li>• The fuse of mains power is blown out</li> </ul>	<ul style="list-style-type: none"> <li>• Check and connect the cables</li> <li>• Replace the fuse</li> </ul>
Battery Fault indicator is constantly on after starting up	<ul style="list-style-type: none"> <li>• Wrong connection of backup power cable</li> <li>• The backup power supply is out of power or damaged</li> </ul>	<ul style="list-style-type: none"> <li>• Check the relevant backup electrical plug-ins to ensure that the backup electrical connection is normal</li> <li>• In the case of AC power supply, turn it on for more than 24 hours. If the fault cannot be eliminated, the backup power supply needs to be replaced</li> </ul>
Fault indicator of zone is constantly on	<ul style="list-style-type: none"> <li>• Devices disconnected</li> <li>• Devices damaged</li> <li>• Poor contact between device and base</li> <li>• Bus short circuit</li> </ul>	<ul style="list-style-type: none"> <li>• Check the connection</li> <li>• Replace the device</li> <li>• Re-install the device and make sure the proper installation</li> <li>• Check the circuit. After the short circuit fault is addressed, FACP will reset after 1 minute</li> </ul>
No alarm sound	<ul style="list-style-type: none"> <li>• Loose connection with Buzzer terminals</li> <li>• Buzzer damaged</li> </ul>	<ul style="list-style-type: none"> <li>• Insert the Buzzer terminals again</li> <li>• Replace Buzzer</li> </ul>

# 6 Maintenance

To keep your device in good working condition, please follow these requirements.

- Simulate alarm test: Test the device once half a year (recommended).
- Battery check: A visual inspection should be made once a quarter and discharging once half a year to ensure they are in good serviceable condition.



When reporting a backup power failure, check the connection and wiring of the backup battery. When the backup battery continuously works for more than 8 hours, it may also report a backup power failure due to low voltage.

- Fuse maintenance: Check the fuse when the main and backup power supply is abnormal.

If the fuse is burnt out, replace the fuse with same specification.

Fuse	Fuse
Fuse -TMDT2AL250V-2A-250VAC- Slow Melt Glass Tube - Ø5.2x20mm	250V-2A